



# Wire Patterns for Tamar Railings


PULPIT materials – 3.75" of 2mm wire  
and two posts of 0.6".  
Bend as shown, and attach two posts





TOP



SIDE




Side Rails – make 2. Each comprises one length of  
5.75" of 1.5mm wire. and 4 0.8" long posts




This cutting  
sheet  
should be  
viewed  
together  
with the  
Web Site  
pictures for  
the Tamar  
Fittings

# Tamar Rear Railings

Rear Rail Materials – 10.5" of 1mm wire. 6" of 2mm wire. 10 0.8" posts and cross pieces to measure.



Side View



Rear View


Make the basic shape in 1mm wire, then add the 2mm rear cross-piece as shown.

This cutting sheet should be viewed together with the Web Site pictures for the Tamar Fittings



Top View

# Tamar Bridge Unit



Bridge Materials – 1 piece 1.5mm wire at 5" long, and 1 piece 1.5mm wire 4.5" long. 8 pieces 1.5mm wire at 0.15" long.

Bend both long pieces as shown, glue short links onto lower hoop and join upper hoop to these. See web site – Tamar Fittings...

This cutting sheet should be viewed together with the Web Site pictures for the Tamar Fittings